



## The standard 'overhead' join – example of a left hand circuit

- 6 WATCH FOR EXISTING CIRCUIT TRAFFIC AND ADJUST YOUR PATH TO SEQUENCE SAFELY.

