

# Where are you flying today? Who will you be talking to?

## Lower Airspace Radar Service (LARS)

LARS provides one of three services for traffic outside controlled airspace:

- Basic Service
- Traffic Service
- De-confliction Service

### Calling for a LARS service

Selected the frequency, listen out for a few seconds to check how busy it is, then call up:

“(Station) Radar, G-ABCD request (Basic/Traffic/De-confliction) Service”

When the Controller asks, provide your flight details clearly and concisely:

- Type
- Origin
- Destination
- Altitude
- Location

Read back the type of ATS being given, plus any executive instructions such as Heading, Level, Speed, Squawk, Clearance.

### 8.33 kHz changes

Pilots must refer to AIP supplements and associated NOTAMs to check 8.33 kHz changes before each flight.

#### LARS WEEKDAY ONLY SERVICE

Frequencies in boxes denote weekday service only.

